

Torsa Cable Repositioning Instructions

Important: Please read all instructions before starting adjustment.

If the Torsa tilt lock does not disengage while in the reclining position follow the corrective steps below.

1. Required Tools and Materials

- a. Flat head screwdriver

2. Repositioning the Tilt Lock Cable

- a. Place the chair upside down on a clean elevated surface (possibly the corner of a sturdy table). The Tilt Lock Paddle is shown in Photo A.
- b. Hold the cable at the edge of the retaining area shown in Photo B and lift up firmly. The cable should dislodge from the clip. If necessary, use a flat head screwdriver to push the cable out from the bottom.
- c. Note the original position of the cable and the revised position of the cable as shown in Photo C. Pull the cable to locate the thin section over the revised position clips and set firmly with the flat head screwdriver as shown in Photo D. Return the chair to service.

